



YI Technologies, Inc. > YI Action Camera	
Q Search	
4 coaron	

YI Action Camera

Small, yet Powerful.

Overview

Common Issues

How do I change my camera's Wi-Fi name and password?

How can I restore the camera to factory settings?

How do I upgrade the camera's firmware?

How can I contact customer support?

What's the minimum system requirement for mobile phones?

How do I clean the camera's body? What are the optional accessories for Yi Action camera? See all 8 articles **Connecting the Camera** Why can't I connect to the camera's Wi-Fi? How do I connect the App to the camera? What's the default Wi-Fi camera's name? How do I connect the App to a second camera? Why can't I find the camera's Wi-Fi? How do I pair the Bluetooth remote? Video/Photo What are the video resolution modes? I'm unable to view the media content I've captured? How do I share my photos and videos to social networks? Why can't I take a snapshot while I'm recording video? Why can't I take photos or record videos? What video standard does the camera support?

See all 20 articles

Battery

Why is the camera so hot when it's charging?

How long does it take to charge the battery?

What's the battery life in normal conditions?

How do I save the camera's power?

How do I avoid damaging the battery ejection sheet?

How do I insert and remove the battery correctly?

Micro SD Card

Why does the app show the message "No SD card" when I have already inserted an SD card into the camera?

What type of SD card do I need?

How can I view the photos and videos saved on my SD card?

Powering On/Off

Why does the camera turn off automatically?

Other Issues

Why does the camera lag in dark environments?

Can I set white balance manually in the APP? What about exposure compensation?

Why isn't the camera beeping or the LED lights flashing while I'm using it?

What are the HDMI and USB port types?

What is a .thm file?

How can I make the camera's beep louder?

See all 7 articles

© 2017 YI Technologies, Inc.